


User Interface Guide

Binding the Device



Press binding button for 5 secs.

Right LED will flash Amber for up to 2 mins whilst binding.

Successful binding is confirmed by right LED showing permanent green for 5 secs.

After 2 minutes binding timeout (if unsuccessful). TRV will return to normal default mode.

Direct Status Check



Short press binding button


Green flash (5 secs) indicates no issue.

Permanent amber (5 secs) indicates the battery is low.

Permanent red (10 secs) indicates a mounting issue.

Red flash (10 secs) indicates a signal issue (signal lost or not bound).


Turn the device OFF (5°C)



To turn the TRV off, Short press on/off button.

The left LED will flash Amber for 5 secs.


Turn the device ON(21°C)



To turn the TRV on, Short press on/off button.

The left LED will flash Green for 5 secs.

Unbinding the Device



Press binding button for 10+ secs.

After 10 seconds LED will flash Red for 10 secs. Factory reset is performed & button can be released.

Bei Tastendruck
egal welche) beide rot:
Lokale Bedienung ist
gesperrt.